

**Product Name :**  
Telescopic Leveling Staffs Set

**Product Code :**  
LIM-CAT-L0026-00005



**Description :**

Telescopic Leveling Staffs Set

**Technical Specification :**

Telescopic leveling staffs (set)  
All staffs are delivered with bag and bubble.  
Telescopic extendable staffs, short transport size and low weight make the staffs comfortable to handle.  
E-graduation on the front side with alternately red and black print.  
Backside with mm-graduation for measuring clear heights. Simply extend the segments, the result can be read at the junction to the next segment.  
Assorted sizes 3, 4, 5 mtrs (1 of each)  
The telescopic levelling staffs are sturdy and meet the requirements of daily use on the jobsite perfectly.  
The imprint is protected by projected profile edges.  
Solid push-button mechanism for secure locking of the telescopic segments.  
The segments slide easily without jamming.

Telescopic Leveling Staffs Set, Telescopic Leveling Staffs Set Bulk Suppliers, Telescopic Leveling Staffs Set Tools, Telescopic Leveling Staffs Set Telescopic Leveling Staffs Sets, Telescopic Leveling Staffs Set Manufacturers, Telescopic Leveling Staffs Set Suppliers from India, China, Kenya.

---

## Laboratory instruments manufacturers India

