

Product Name :
Soil Permeability Apparatus Universal

Product Code :
LIM-CAT-L0044-00024



Description :

Soil Permeability Apparatus Universal

Technical Specification :

Soil Permeability Apparatus Universal

A set of three glass stand pipes a stand with nine glass tubes of 6mm, 10mm, 20mm, 25mm, 40mm, 50mm, 60mm, 70mm, 75mm bore.

75mm bore tube is provided with overflow arrangement for constant head tests.

The remaining tubes are used for falling head test.

Overhead tank made of steel, 3 7 .Scm dia x 1mtr. high.

It is provided with an inlet port at the top and size outlet at bottom with cocks and air inlet and water filling tube on top .

An arrangement is provided to indicate the water level.

An extra meralic tube having 5mm 16mm Internal Diameter and 1 mtr. long is also supplied 2.6 kg x 310 mm

controlled fall and Rammer 4.89 kg x 450 mm controlled fall. Spares : Pair of top and bottom

Porous stones for penneameter mould.

