

Product Name :
Core Cutter

Product Code :
LIM-CAT-L0044-00039



Description :

Core Cutter

Technical Specification :

Core Cutter

This is used for determination of in situ dry density of natural or compacted fine grained soil, free from aggregates. A cylindrical cutter is used to extract a sample of the soil with the help of a dolly and rammer. From the weight, density and the moisture, and dry density of the soil is readily calculated.

Cylindrical core cutter made of steel, 127.3mm Long and 100mm internal diameter.

Steel dolly, 25mm high with a lip to enable it to be located on top of the core cutter, rammer with detachable steel rod