

**Product Name :**  
Marshall Extruder Hydraulic

**Product Code :**  
LIM-CAT-L0049-00017



**Description :**

Marshall Extruder Hydraulic

**Technical Specification :**

The extractor frame is used for taking out soil samples compacted or undisturbed, from 100mm dia and 150mm dia cylinders such as Core Cutters, Proctor moulds, C.B.R. moulds etc.

**Specification:**

It consists of a 50Kn capacity hand operated, hydraulic jack mounted on a suitable frame.

Two plungers, one for 4"/100mm dia and the other of 6"/150mm dia moulds are supplied Height of thrust plate is adjustable.