

Product Name :
T- Slot Milling Cutters

Product Code :
LIM-CAT-L0065-00001



Description :

T- Slot Milling Cutters

Technical Specification :

The cutting edge is sharp and not easy to break. High-frequency welding process is adopted for the connection between the cutter head and the cutter body.

Universal chamfered round shank, easier clamping, stable cutting process.

Easy to Use: Used on drilling and milling machines, machining centers. Properly reduce the cutting speed and feed can prolong the life of the milling cutter.

Add cutting fluid to protect the cutting edge and make the cutting smoother when working.

Tips: The longer the length of the tool clamped by the chuck, the better. If the clamping length is shorter, you need to lower the feed rate and cutting speed to reduce vibration and extend the tool life.

HSS, T- slot cutter 1/4" – 3/4".