

Product Name :
Industrial Air Compressor

Product Code :
LIM-CAT-L0072-00094



Description :

Industrial Air Compressor

Technical Specification :

Industrial Air Compressor

Workshop compressor with high air capacity.

Suction capacity = 1,500 ltr/min.

Effective discharge capacity 1,050 ltr/min.

2-cylinder block compressor / in-line compressor.

Cast Cylinder

Boiler 500 ltr / 11 bar max. pressure - horizontal version

Electric motor 7,5 KW / 400 V

Pressure switch with motor protection relay and start-up relief valve

Dimensions : L = 2050 H = 1330 D = 650

Weight : 180 KG

Incl. 1 set of high quality rubber buffers - vulcanized / galvanized for proper installation

Industrial version - with robust 2-cylinder block compressor,

2-stage compression method with pre-compressor, post-compressor,

Intercooling and large air outlet cooler.

Incl. All necessary papers - type approval papers.

Incl. Detailed illustrated operating and maintenance instructions.



Laboratory instruments manufacturers India